




# User manual / Assembly instructions Deponti Glass Sliding Doors

## Type Deponti Fiano

Version: EN – Marc 2026



[www.deponti.com](http://www.deponti.com)



# Contents

1. Introduction	3
2. Safety precautions and warnings	3
3. Product description	5
4. Parts overview	6
4.1 Exploded view	6
4.2 Delivery inspection	6
4.3 Parts list	7
5. Preparation for assembly	9
5.1 Conditions for assembly	9
5.2 Inspection of tools and accessories	10
5.3 Measuring & determining dimensions	11
5.3.1 Height dimension	12
5.3.2 Overlap dimension	12
6. Assembly	13
6.1 Pre-installing wheel sets in H-profiles	13
6.2 Pre-installing the tracking system in H-profiles (option)	14
6.2.1 Pre-installing the tracking system in H-profiles without Side or centre lock	14
6.2.2 Pre-installing the tracking system in H-profiles with Side or centre lock	17
6.3 Pre-installing glass panel	20
6.4 Installing U-profiles for the side connection (option)	22
6.4.1 Cutting to size and pre-drilling the U-profiles	22
6.4.2 Installing the U-profiles	23
6.5 Installing top and bottom rails with side connection (option)	24
6.5.1 Cutting to size and pre-drilling the top rail	24
6.5.2 Cutting to size and pre-drilling the bottom rail	25
6.5.3 Installing the top and bottom rails	26
6.6 Installing top and bottom rails	27
6.6.1 Cutting to size and pre-drilling the top rail	27
6.6.2 Installing the top rail	28
6.6.3 Cutting to size and pre-drilling the bottom rail	29
6.6.4 Installing the bottom rail	30
6.7 Placing the glass panels	31
6.8 Adjusting the glass panels	33
6.9 Installing handle (option)	34
6.10 Installing the glass stopper (optional)	35
7. Maintenance	36
8. Disposal of waste	36
9. Warranty conditions	36
10. Contact	36

KEEP THIS MANUAL IN A SAFE PLACE FOR FUTURE USE!

For the duration and the terms and conditions of the warranty we recommend that you contact your Deponti partner. We also refer you to our General Terms and Conditions of Sale and Delivery which are available on request. Deponti B.V. accepts no liability for any damage or injury resulting from a failure to carefully follow the instructions in this manual or exercise due caution during transport, assembly, use and maintenance of the veranda. As a result of our policy of continuous product improvement, certain product details may differ from what is described in this manual. For this reason the instructions provided only serve as a guideline for installation of the product this manual describes. This manual has been compiled with the utmost care, but Deponti B.V. cannot be held responsible for any errors in this manual or the



consequences thereof. Furthermore, all rights are reserved and no part of this manual may be reproduced in any way whatsoever.

## 1 Introduction

### **Congratulations on the purchase of your Deponti Deponti Deponti Fiano Glass Sliding Door!**

Before you can start enjoying your glass sliding door it must be assembled properly. This manual provides clear instructions for all the steps you must complete for correct assembly of your Deponti glass sliding door. We recommend that you take the time to read the entire manual before you begin assembly. Check whether you have received all the necessary parts before you begin assembly. For your safety, follow all the applicable instructions. This also guarantees the safety of the installed roof. If you should have any questions, please feel free to contact your Deponti partner.




This manual should be kept in a safe, dry and shady place. In the event of damage or loss, the user must request a new copy of the manual from the Deponti partner.

## 2 Safety precautions and warnings



**Important:** Please read the safety precautions and warnings before assembling the glass sliding door.

- During assembly, carefully follow the instructions and guidelines as described in this manual. Never change the order of the steps to be performed. If any aspect of the assembly procedure is unclear, please contact your Deponti partner. We reserve the right to make technical changes without written notice.
- We normally recommend that the glass sliding door be installed by two people (qualified technicians/authorized installers) working together. 
- Check the delivery immediately upon receipt. In the event of damage or an incomplete delivery please contact your dealer immediately.
- The materials must be stored in a dry, ventilated area, not exposed to direct sunlight.
- Open the packaging carefully. Make sure you do not damage the product.
- To prevent damage to your glass sliding door, place the parts on a soft, clean, flat surface. **Never** place the glass panels directly on the ground! Tempered glass is easily scratched. Make sure it does not get scratched. Be particularly careful with the edges and corners of the glass panels.
- **Never** stand on the glass panels.



- The addition or removal of parts, or the use or installation of materials other than in the prescribed manner, may adversely affect the safety of the glass sliding door and is therefore strongly discouraged!
- Tempered glass can **NOT** be ground or cut.
- Cordon off the assembly location so that others are kept at a distance.
- Always wear the correct protective clothing (work gloves, dust mask, safety glasses, shoes with non-slip soles, etc.) when performing the work.
- Always place a ladder on a firm, stable surface.
- Install the glass sliding door on a flat, stable foundation or surface. Make sure all fasteners are properly tightened. Check this regularly.
- The type of fastener to be used for the top rail, bottom rail and U-profiles for the side connection depends on the type of surface (metal, concrete or wood). Which types of fasteners are to be used must be determined by the installer, so fasteners are not included.
- Contamination may accumulate in the bottom rail system. To obtain maximum service life, it is important to keep the rail (track system) clean.
- Before first use the glass sliding door must first be thoroughly rinsed with clean water.
- Use plenty of water, soft material and a sponge for cleaning.  
Use only neutral cleansers. No acids or alkalis.  
Solvents (washing-up liquid and glass cleaner) can be used for removing greasy contamination.
- Be careful **not** to pinch fingers and limbs between the glass panels and/or side connection profiles.
- Dispose of the product in accordance with local laws and regulations.
- Deponti B.V. accepts no liability for damage or injury caused by failure to strictly follow the safety regulations and instructions in this manual or exercise due caution during assembly, use and maintenance of the product and any related accessories. Deponti B.V. is not responsible for any form of damage.



## 3 Product description

The Deponti Deponti Fiano glass sliding doors are ideal for use as a door for your veranda, veranda, garden house, cabin, balcony, etc.

The Deponti Deponti Fiano glass sliding doors consists of glass panels and aluminium top and bottom rails.

The glass panels can be slid to the left and right in a 2, 3, 4, 5, 6 or 7-track guide rail. The system is fitted with bottom wheel guides, which is to say that there is an aluminium H-profile on the bottom of each glass panel which is fitted with a wheel set with plastic runner wheels that run along the bottom rail. The wheel set are height adjustable, allowing perfect adjustment of the glass panels.

The top rail, as delivered, has a height of 60 mm. The top rail has double brush profiles, to provide stable guidance. The bottom rail has a low bottom guide with a removable connecting/runner rail. There are water drainage slots in the bottom rail to allow rainwater to drain from the rail.

The glass panels are made of 10-mm-thick tempered safety glass and have an attractive ground finish at the edges. The glass panels are available with an overall height of 200 to 250 cm and a width of 64, 82, 98 or 104 cm.

The glass sliding doors can optionally be fitted with handles and catches so that all the panels automatically slide one after the other when the glass sliding door is opened.

The mounting position of these catches in the H-profile is variable, so the overlap of each panel can be set separately.

### Details

Colours	RAL9016 / RAL9001 / RAL7024 / RAL9005 / Brute
Glass type	Tempered safety glass
Glass thickness	10 mm
Number of tracks	2/3/4/5/6/7-track guide rails (41, 60, 79, 98, 117 and 136mm in width)
Panel width	64/82/98/104 cm
Installation height	200, 210, 215, 220, 225, 230, 235, 240 and 250 cm


The type of fastener to be used for the top rail, bottom rail and U-profiles for the side connection depends on the type of surface (metal, concrete or wood). Which types of fasteners are to be used must be determined by the installer, so fasteners are not included.

Through use of a rectangular hollow section (RHS) and/or U-profiles (horizontal/vertical), the rough opening can be made level and plumb. Both the RHS and the U-profiles are available as optional parts.



## 4 Parts overview

### 4.1 Exploded-view




### 4.2 Delivery inspection


This manual shows a Deponti Deponti Fiano Glass Sliding Door with representative dimensions (WxH) of 3.16 x 2.2 m, consisting of four glass panels with an overlap of 40 mm in a one-sided arrangement with 4-track rails. Catches are also used in this system. This merely serves as an example. The type and number of components supplied depends on your order. **Note:** Always carefully check the delivered items against the accompanying delivery note to ensure that the quantity and quality are correct. Any visible defects must be reported in writing within 7 days of delivery.




### 4.3 Parts overview




01. H-profile




02. Wheel set




03. Sheet metal screw  
Phillips 3.9 x 6.5




04. Tracking system  
(option)




05. Rubber plug  
for tracking system  
(option)




06. Adjustment screw  
for tracking system  
(option)




07. Glass panel




08. Glass panel  
for screw-in  
handle (option)




09. U rubber




10. H-profile cover




11. Screw 4.2x16  
Countersunk Phillips  
head




12. Cap



13. U-profiles for side connection and compensation of uneven floor (option)




14. Top rail  
15. Brush profiles




16. Bottom rail  
17. Removable connecting/runner rail


**Other options:**



18. Rubber seal ring for handle




19. Screw-in handle outside




20. Screw-in handle inside

or



21. Aluminium stick-on handles with 3M VHB tape



22. Rectangular hollow section (RHS) for foundation



## 5 Preparation for assembly

### 5.1 Conditions for assembly

#### Ground & rough opening

- A good flat stable surface is required for installation of the glass sliding door.
- The bottom rail must be sufficiently anchored, via RHS, concrete strip or tiles.
- The location where the glass sliding door will be placed must be construction-ready and free of obstacles (garden furniture, flower boxes, etc.) so installers can perform their work without hindrance.
- Any obstacles and utility lines (e.g. power cables, etc.), must have been removed from the ground.
- The place where the top rail will be placed must be firm, even and flat.

#### Dimensions

- A Deponti glass sliding door is available for an overall height of 2000 to 2500 mm.
- A Deponti glass sliding door has a maximum width of eight metres.

#### Screws and drilling

- Tempered glass can **NOT** be drilled, ground or cut.
- Drill screw holes in the top and bottom rails, approximately 3 mm and 100 mm from the edge, with a distance of approximately 70-90 cm to the next two holes.
- Mount the top and bottom rails with countersunk-head stainless steel screws.



Note: If you continue to turn the stainless steel screws after they are tight, the screw head may break off. It is recommended that you screw carefully, with the torque limiter on your drill set properly.























#### Remove protective film

- It is recommended that the protective film be removed from the aluminium parts at the last possible moment, to prevent damage.

**Warranty is void if the Deponti Deponti Fiano Glass Sliding Door is not assembled and installed in accordance with the instructions.**




## 5.2 Inspection of tools and accessories





## 5.3 Measuring & determining dimensions

- Check the rough opening dimensions.
- Verify that the rough opening is level and plumb. The rough opening can be made level and plumb through use of a rectangular hollow section (RHS) and/or U-profiles (horizontal/vertical).
- Check whether the ground is stable, with an adequate foundation (e.g. RHS, concrete strip or tiles).



- B: Overall width  
 H: Overall height  
 D: Depth of wall, façade or veranda post







## 6.2 Pre-installing the tracking system in H-profiles (option)


**Please note:** depending on if you wish to install a Side or Centre lock, the tracking system needs to be installed accordingly. When installing a Side or Centre lock, follow the instructions at 6.2.2 (page 17). For optionally installing the tracking system without a Side or Centre lock, follow the instructions below.

### 6.2.1 Pre-installing tracking system in H profiles without Side or Centre lock


The glass sliding doors can optionally be fitted with the tracking system so that all the panels automatically slide one after the other when the glass sliding door is opened. The mounting position of the tracking system in the H-profile is variable, so the overlap of each panel can be set individually.

This manual shows the situation in which the panels slide one after the other when the glass sliding door is opened. The panels overlap by 40 mm.


**1.** Place the H-profile with the bottom facing up. Place one tracking system in the side of the H-profile of the first and last glass panel. Press the rubber plug (bumper) into the round hole of the tracking system.




2. Tighten the two set screws of the tracking system with the Allen key.



3. Place two tracking systems in the side of the H-profile of the middle glass panels. Press the rubber plugs (bumpers) into the round hole of the tracking systems.



4. Tighten the set screws of the tracking systems with the Allen key.






### 6.2.2 Pre-installing tracking system in H profiles with Side or Centre lock


When installing the Side or Centre lock, it is required to add the tracking system for the lock to function correctly. The trackers (A) ensure that all panels automatically slide along when opening or closing the one of the panels. The stoppers (B) are optional but recommended. The mounting position of the tracking system in the H-profile is variable, so the overlap of each panel can be set individually.

This manual shows an example situation in which 4 panels are present. We start with the “front” panel, which is the panel on which the lock is mounted (1). We then move on to the panels in the middle (2) and finally the rear panel (3). This panel is fixed to the wall or the U-profile (4, optional).






1. Start with the front panel (1).




Place the H-profile of (1) with the bottom side up. Two sets of running wheels are pre-mounted in the H-profile. Dismantle the wheels on the side where the side or centre lock will be placed and reinstall them at least 60 mm from the side. This ensures that when the optional "stopper" tracker (B) is fitted next to it later, the next panel will have enough distance from the handle bar to be operated comfortably.




2. Place one tracker in both ends of the H profile (A and B). The stopper at the side of the Side or Center lock (B) should be placed next to the wheel assembly, at minimum 39 mm from the side. Place both trackers with the protruding piece facing the other panels.

3. Tighten the adjustment screws of the trackers with the Allen key. Press the rubber caps (buffers) into the round holes of the trackers.




4. Depending on your Deponti Deponti Fiano installation, you will have one or multiple in between panels (2).




Place the H-profile of the panel (2) with the bottom side up. Place the stopper (B) against the running wheels on the side where the Side or Centre lock will be placed. The stopper prevents the panels from slipping and colliding with the handle of the lock. Place it with the protruding piece facing the rear panel (3).

5. Insert 2 more trackers (A) in the H-profile, one in each end. Place the tracker on the wall side with the protruding piece facing the rear panel (3) and the one at the side of the Side or Centre lock with the protruding piece facing the front panel (1).




6. Tighten the adjustment screws of the trackers with the Allen key. Press the rubber caps (buffers) into the round holes of the trackers. Repeat these steps for all middle panels (2).







7. Place the H profile of the rear panel (3) with the bottom side up. Place at the end of the H profile on the side of the Side or Centre lock one tracker (A), with the protruding part facing the other panels.



8. Tighten the adjustment screws of the tracker with the Allen key. Press the rubber caps (buffers) into the round holes of the tracker.

### 6.3 Pre-installing glass panel


1. Place the glass panel on a stable, horizontal surface (a table or sawhorses) at working height.
  2. Slide the U-rubber over the entire underside of the glass panel.
  3. Cut the rubber to size.
- Repeat this action for all the panels.




**TIP:** Drip washing-up liquid or glass cleaner onto the U-rubber of the glass panel. Spread it evenly over the surface.

4. Place the H-profile with the open side (glass side) over the U-rubber, and tap the H-profile firmly in place. Do this for all the panels.

**Note:** In the case of a glass panel with milled out handle (=optional), make sure the tracking system is on the correct side!



5. Fit the H-profile cover on both ends of the H-profile with 4.2x16 stainless steel screws
6. Then push the caps on.






## 6.4 Installing U-profiles for the side connection (option)

**NOTE:** If you do not have u-profiles for the side connection, proceed to section 6.6 installation of top and bottom rails.

**NOTE:** If there is an even number of glass panels: screw in the middle. If there is an odd number of panels, do not screw in the middle, as the glass panel may then hit the screw.

### 6.4.1 Cutting to size and pre-drilling the U-profiles


1. Place the U-profiles horizontally at working height (on a table or sawhorses).
2. Measure the overall height (H) and mark this on the U-profiles.
3. Saw the U-profiles to the right length.
4. Mark the holes along the centreline of the profiles, 10 cm from the end, with a distance of 70-90 cm to the next two holes. Drill the holes with a 4 mm drill bit.





### 6.4.2 Installing the U-profiles

1. Place the U-profiles in the rough opening, against wall or post.
2. Check that the U-profiles are plumb.
3. Screw the U-profiles to wall or post. The type of fastener to be used depends on the type of surface (metal, concrete or wood).
4. Now measure dimension B1 for the length of the top and bottom rails.






## 6.5 Installation of bottom and top rails in combination with side

### 6.5.1 Cutting to size and pre-drilling the top rail

1. Place the top rail horizontally at working height (on a table or sawhorses).
2. Measure dimension B1 (overall width between the U-profiles) at the top of the rough opening and mark this on the top rail.
3. Saw the top rail to the right length.
4. Mark the holes along the centreline of the profile (for 4-track rail, in the centre of a track!), 10 cm from the end, with a distance of 70-90 cm to the next two holes. Drill the holes with a 4 mm drill bit.


**TIP:** Preserve the water drainage openings as much as possible.





### 6.5.2 Cutting to size and pre-drilling the bottom rail


1. Place the bottom rail horizontally at working height (on a table or sawhorses).
2. Measure dimension B1 (overall width between the U-profiles) at the bottom of the rough opening and mark this on the bottom rail.
3. Saw the bottom rail to the right length.
4. Mark the holes along the centreline of the profile (for 3- or 5-track rail, in the centre of a track!), 10 cm from the end, with a distance of 70-90 cm to the next two holes. Drill the holes with a 4 mm drill bit. Countersink the holes to  $\varnothing 10$  mm at the top side.





### 6.5.3 Installing the top and bottom rails

1. Place the top rail between the U-profiles and slide it against the top of the rough opening.
  2. Check that the top rail is level.
  3. Screw the top rail to wall or post. The type of fastener to be used depends on the type of surface (metal, concrete or wood).
  4. Place the bottom rail between the U-profiles and slide it against the ground.
- Note:** Make sure the slot for water drainage is on the outside.
5. Check that the bottom rail is level.
  6. Screw the bottom rail to the ground or RHS. The type of fastener to be used depends on the type of surface (metal, concrete or wood).






## 6.6 Installing top and bottom rails

### 6.6.1 Cutting to size and pre-drilling the top rail


1. Place the top rail horizontally at working height (on a table or sawhorses).
2. Measure dimension W (overall width) at the top of the rough opening and mark this on the top rail.
3. Saw the top rail to the right length.
4. Mark the holes along the centreline of the profile (for 4-track rail, in the centre of a track!), 10 cm from the end, with a distance of 70-90 cm to the next two holes. Drill the holes with a 4 mm drill bit.





### 6.6.2 Installing the top rail


1. Place the top rail against the top of the rough opening.
2. Check that the top rail is level.
3. Screw the top rail to wall or post. The type of fastener to be used depends on the type of surface (metal, concrete or wood).





### 6.6.3 Cutting to size and pre-drilling the bottom rail

1. Place the bottom rail horizontally at working height (on a table or sawhorses).
2. Measure dimension W (overall width) at the bottom of the rough opening and mark this on the bottom rail.
3. Saw the bottom rail to the right length.
4. Mark the holes along the centreline of the profile (in the centre of a track!), 10 cm from the end, with a distance of 70-90 cm to the next two holes. Drill the holes with a 3 mm drill bit.





#### 6.6.4 Installing the bottom rail


**Note:** The bottom rail must be sufficiently anchored, via RHS, concrete strip or tiles.

1. Place the bottom rail in the rough opening on the ground.

**Note:** Make sure the slots for water drainage are on the outside.

2. Check that the bottom rail is level and properly aligned with the top rail.

3. Screw the bottom rail to the ground or RHS. The type of fastener to be used depends on the type of surface (metal, concrete or wood).







## 6.7 Placing the glass panels

**Note:** When placing the glass panels, always make sure they are placed in the correct track.

**1.** Lift the first glass panel into the first track of the top rail and then lower the glass panel into the same track on the bottom rail.

**Note:** Make sure the tracking system is on the correct side!







2. Lift the second glass panel into the second track of the top rail and then lower the glass panel into the same track on the bottom rail.

**Note:** Make sure that the tracking system on the second panel falls behind the tracking system on the first panel at the overlap!

3. Repeat the steps until all the glass panels are in position.






## 6.8 Adjusting the glass panels

A Phillips screwdriver can be used to perfectly align the glass panels.

1. Remove the cap.
2. Use the Phillips screwdriver to adjust the runner wheels to the perfect height.
3. Fit the cap.
4. Repeat this for all the glass panels.

**Congratulations!** Your Deponti Deponti Fiano Glass Sliding Door is now ready!





## 6.9 Installing handle (option)


The glass sliding door can optionally be equipped with stick-on handles or screw-in handles.

### Installing stick-on handles:

1. Close the sliding glass door completely and mark the position where the stick-on handles should be located (approximately 105 cm from the ground and 10 cm from the side).
2. Degrease the glass panel where the handle will be placed.
3. Remove the film from the 3M VHB tape.
4. Affix the handles to both sides of the glass panel. Press firmly!

### Installing stainless steel screw-in handles:

1. Place the sealing ring on the screw-in handle (19).
2. Place the screw-in handle (19) through the round mounting hole in the glass panel on the outside of the sliding glass door.
3. On the inside, place the second sealing ring on the screw-in handle (19).
4. Screw the grip ring (20) onto the screw-in handle (19).






## 6.10 Installing the glass stopper (optional)


### 6.10.1 Preparing the glass stopper

1. Place the rubber caps on both sides of the glass stopper.



### 6.10.2 Installing the glass stopper

1. Press the glass stopper into the top rail. Make sure you place the glass stopper in the track of the glass panel you want to "stop".
2. Move the glass stopper to the desired position and secure it by tightening the adjustment screw against the top rail.





## 7 Maintenance

We recommend that you maintain and clean your veranda at least once a year. Check whether the screw connections are tight. If not, tighten them firmly.

The aluminium profiles and roofing sheets that are dirty can be cleaned with lukewarm water and a cleaning product.

- Use a soft brush or sponge.
- Never use abrasives, aggressive solvents or a pressure washer.
- Wet first and rinse off with lots of water, and then wipe with a soft cloth.

## 8 Disposal of waste

Dispose of the product according to local laws and regulations.

## 9 Warranty conditions

Warranty in accordance with the warranty conditions and Deponti's general terms and conditions. These can be found on the website [www.deponti.com](http://www.deponti.com).

The powder coating has a 5-year warranty. Please note, the powder coating warranty of aluminum parts is two years when the product is placed in a place where it comes into contact with salty or chemical steam (such as harbors, coast and swimming pools).

## 10 Contact

**IMPORTANT:** Your Deponti partner is your first point of contact for questions and comments.

